Before you get started, ensure that all the drivers required for your USB device(s) are installed.

Network Connect

Direct Connect

1 Place the Local Extender where desired and connect a CAT 5e/6/7 patch cable from the Link port (RJ45) to a network switch or wall network port connected to a switch.

Max 100m between network devices

Place the Remote Extender where desired.

Link port (RJ45) to a network switch or

Remote Extender (back view)

wall network port connected to a switch. Connect the Remote Extender to the AC adapter and plug it into a power source.

Max 100m between network devices

Connect a CAT 5e/6/7 patch cable from the

3

ц ,

- Connect the Local Extender to the computer using the included USB 2.0 cable.
 Local Extender (back view)
 Computer
- Attach USB device(s) to the Remote Extender.



Package Contents:

• USB 2.0 RG2304N/S/GE-LAN Local Extender

USB 2.0 RG2304N,


2304S or 2304GE-LAN

4-Port USB LAN or CAT 5e/6/7 Extender System


> Quick Start

Guide

- USB 2.0 RG2304N/S/GE-LAN Remote Extender
- USB 2.0 Cable
- AC Power Adapter
- Country Specific Power Cord
- Quick Start Guide



(I)







Certification and Compliance

FCC Radio Frequency Interference Statement Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

CE Statement

We, Icron Technologies Corporation, declare under our sole responsibility that the USB 2.0 RG2304 Series, to which this declaration relates, is in conformity with European Standard EN 55022, EN 61000 and EN 55024.

IC Statement

This Class B digital apparatus complies with Canadian ICES-003.

WEEE Statement

The European Union has established regulations for the collection and recycling of all waste electrical and electronic equipment (WEEE). Implementation of WEEE regulations may vary slightly by individual EU member states. Please check with your local and state government guidelines for safe disposal and recycling or contact your national WEEE recycling agency for more information.

Product Operation and Storage

Please read and follow all instructions provided with this product, and operate for intended use only. Do not attempt to open the product casing as this may cause damage and will void warranty. Use only the power supply provided with this product. When not in use, product should be stored in a dry location between -20°C and 70°C.

Icron Technologies Corporation 4664 Lougheed Hwy. Suite 221 Burnaby, BC, V5C 5T5, Canada +1 604 638 3920

