USB 2.0 RG2311

1-Port USB 2.0 100m (330 ft) CAT 5e/6/7 Extender System with Flexible Power

Quick Start Guide

Product Contents:

- USB 2.0 RG2311 Local Extender
- USB 2.0 RG2311 Remote Extender
- USB 2.0 Cable
- AC Power Adapter
- Country Specific Power Cord
- Quick Start Guide

EXTREME USB®

Before you get started, ensure that all the drivers required for your USB device(s) are installed.

1 Place the units where desired, and connect the CAT 5e/6/7 (solid core) extension link cabling into the Link ports (RJ45) of the Local and Remote Extenders.

2 Connect the power adapter into your desired unit – Local Extender or Remote Extender.

Plug the power adapter into either the local or remote unit

Local Extender

Remote Extender

(CAT 5e/6/7 cable not included)

Max 100m

3 Connect the Local Extender into your computer using the included USB 2.0 cable.

Computer

4 Attach your USB device to the Remote Extender.

Certification and Compliance

FCC Radio Frequency Interference Statement Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

CE Statement
We, Icron Technologies Corporation, a Maxim Integrated brand, declare under our sole responsibility that the Icron USB 2.0 RG2311, to which this declaration relates, is in conformity with European Standards EN 55024, EN 55032, EN 61000, and RoHS Directive 2011/65/EU + 2015/863/EU.

IC Statement
This Class A digital apparatus complies with Canadian ICES-003.

WEEE Statement
The European Union has established regulations for the collection and recycling of all waste electrical and electronic equipment (WEEE). Implementation of WEEE regulations may vary slightly by individual EU member states. Please check with your local and state government guidelines for safe disposal and recycling or contact your national WEEE recycling agency for more information.

Product Operation and Storage
Please read and follow all instructions provided with this product and operate for intended use only. Do not attempt to open the product casing as this may cause damage and will void warranty. Use only the power supply provided with this product. When not in use, product should be stored in a dry location between -20°C and 70°C.