USB 2.0 RG2324/ USB 2.0 RG2344

4-Port USB 2.0 Fiber Extender System

Quick Start Guide

Before you get started, ensure that all the drivers required for your USB device(s) are installed.

1 Place extenders where desired and connect the fiber cable to the Link ports (SFP) on the Local and Remote Extenders.

Local Extender (back view)

Remote Extender (back view)

(LC-LC crossover duplex cable not included)

Max 500m multimode fiber for RG2324
Max 10km singlemode fiber for RG2344

2 Connect the Local Extender to the computer using the included USB cable.

Local Extender (front view)

Computer

3 Connect the Remote Extender to the AC adapter and plug it into a power source.

Remote Extender (back view)

4 Attach USB device(s) to the Remote Extender.

Remote Extender (front view)

Package Contents:

- **USB 2.0 RG2324/2344 Local Extender**
- **USB 2.0 RG2324/2344 Remote Extender**
- **USB 2.0 Cable**
- **AC Power Adapter**
- **Country Specific Power Cord**
- **Quick Start Guide**

EXTREME
USB®

Certification and Compliance

FCC Radio Frequency Interference Statement Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

CE Statement
We, Icron Technologies Corporation, a Maxim Integrated brand, declare under our sole responsibility that the USB 2.0 RG2324/2344, to which this declaration relates, is in conformity with European Standards EN 55024, EN 55032, EN 61000, and RoHS Directive 2011/65/EU + 2015/863/EU.

IC Statement
This Class B digital apparatus complies with Canadian ICES-003.

WEEE Statement
The European Union has established regulations for the collection and recycling of all waste electrical and electronic equipment (WEEE). Implementation of WEEE regulations may vary slightly by individual EU member states. Please check with your local and state government guidelines for safe disposal and recycling or contact your national WEEE recycling agency for more information.

Product Operation and Storage
Please read and follow all instructions provided with this product and operate for intended use only. Do not attempt to open the product casing as this may cause damage and will void warranty. Use only the power supply provided with this product. When not in use, product should be stored in a dry location between -20°C and 70°C.

90-01535-B01